

RS4000 Servo Motor Assembly

Part # 40281

Assembly includes new motor (pre-wired), drive arm, mounting plate, terminal strip, motor to mounting plate isolators and drive arm to crank isolator all preassembled and ready for installation.



Advantages to purchasing the complete motor assembly:

- No assembly required, so no chance of losing parts in the field.
- All new isolators are installed between the motor and mounting plate.
- New isolator for crank arm provided.
- New terminal strip ensures clean electrical connections.
- Drops onto the servo quickly and easily.







The pictures above show you the isolators (red arrows) that MUST be in place and in good physical shape when a new motor is installed. Without these isolators you will blow the motor fuse in your panel every time the servo moves in one direction.

Rail Alignment LLC Olathe, KS 66062 Ph: 913 334 8439 Fx: 913 780 9815