


# RS4000 Tripod/Laser Mount---Part # 40535



## 40535 Parts List

| Item No. | Part Number | Description                                         |
|----------|-------------|-----------------------------------------------------|
| 1        | 40105       | <b>Obsolete</b>                                     |
| 2        | 40108       | Catch Block*                                        |
| 3        | Ref Only    | 1/4-20 x 3/4" Socket Head Cap Screw                 |
| 4        | Ref Only    | 5/16-18 x 5/8" Soc Cup Point Set Screw              |
| 5        | 40144       | Bumper*                                             |
| 6        | 40181       | <b>Obsolete</b>                                     |
| 7        | Ref Only    | 6-32 x 5/16" Socket Head Cap Screw                  |
| 8        | 40106       | <b>Obsolete</b>                                     |
| 9        | Ref Only    | 10-32 x 1/2" Cone Point Set Screw                   |
| 10       | Ref Only    | 8-32 x 3/8" Socket Head Cap Screw                   |
| 11       | 40141       | Spring*                                             |
| 12       | Ref Only    | 1/2-13 x 1/2" Socket Head Set Screw                 |
| 13       | 40125       | Plug*                                               |
| 14       | 40098       | Rear Support Block*                                 |
| 15       | 40134       | Teflon Washer*                                      |
| 16       | 40135       | Wave Washer*                                        |
| 17       | 40133       | Knob w/ Lock Insert*                                |
| 18       | Ref Only    | 3/8"-5/16-18 x 3/4" S.H. Shoulder Bolt              |
| 19       | Ref Only    | 8-32 x 3/8" Socket Head Cap Screw                   |
| 20       | 40259       | Line Adjustment Assembly*                           |
| 21       | Ref Only    | 5/16-18 x 1" Socket Head Cap Screw                  |
| 22       | 40096       | Spacer/Wear Plate*                                  |
| 23       | 40092       | Wear Plate                                          |
| 24       | Ref Only    | 10-32 x 1/2" Socket Head Cap Screw                  |
| 25       | 40132       | Snap Ring                                           |
| 26       | 40097       | Spacer/Wear Plate                                   |
| 27       | Ref Only    | 10-32 x 1/4" Socket Head Cap Screw                  |
| 28       | 40145       | Knob Assembly w/ Swivel Pad                         |
| 29       | 40095       | Pointer                                             |
| 30       | Ref Only    | 6-32 x 3/8" Socket Head Cap Screw                   |
| 31       | Ref Only    | 10-32 x 9/16" Socket Head Cap Screw                 |
| 32       | 40099       | Spacer/Wear Plate                                   |
| 33       | Ref Only    | 10-32 x 1/2" Socket Head Cap Screw                  |
| 34       | 40127       | Spacer/Washer                                       |
| 35       | Ref Only    | # 10 Split Lock Washer                              |
| 36       | Ref Only    | 10-32 x 1/2" Socket Head Cap Screw                  |
| 37       | 40128       | Spacer/Washer                                       |
| 38       | 40158       | Front Clamp Frame w/ Insert                         |
| 39       | 40159       | Rear Clamp Frame w/ Inserts                         |
| 40       | 40478       | Rear Support Assembly Complete ( <b>Updated!</b> )  |
| 41       | 40470       | Front Support Assembly Complete ( <b>Updated!</b> ) |

\* Will directly replace the original parts used in the Classic Tripod Assembly.